

**STALLING AFTER WARM UP****ACCORD**

Check fuel system, air boost valve, Electric Air Control Valve (EACV) and EGR control system. Check atmospheric pressure sensor.

**CIVIC 1.5L & CRX (HR & SI)**

Check fuel system, air boost valve, EACV and EGR control system.

**CIVIC 1.6L**

Check EACV, air boost valve and fuel system.

**CRX (STD.)**

Check EACV, fuel system and EGR control system.

**PRELUDE**

Verify proper MAP sensor and carburetor operation.