


Firing Order 1-8-4-3-6-5-7-2



G91A13599